



INSTALLATION GUIDE




Karran USA (866) 452-7726 info@karran.com



- Always inspect sink closely for damage prior to installing.
- Take care when handling sinks as stainless steel sinks may have sharp edges and quartz sinks are heavy.
- Undermount sinks should always be installed by an experienced professional.
- The sink comes with a paper template. Alternatively a DXF file can be downloaded from www.karran.com for use with a CNC machine.
- When installing into solid surface or stone countertops, always use a quality silicone sealant and undermount clips/fasteners provided with your sink. Optional DISC Clips may also be purchased and used.
- Adhere to all local building and plumbing codes.





Installation:

- Check the dimensions of your sink to the paper template dimensions. Adjust your template to adjust your reveal dimensions. Always discuss with the client their expectations for a positive or negative reveal.
- Locate template in desired position on countertop paying attention to faucet placement and cabinet constraints.
- Trace the template and cut the countertop surface on the inside of the line. Polish accordingly.
- 4. Loosely install fasteners by following the countertop manufacturers instructions. Evenly space fasteners.
- 5. Apply a quality silicone to the underside of the countertop around the perimeter of the sink cutout. Position and align the sink in the correct position over the opening.
- 6. Tighten fasteners to secure sink.
- 7. Check alignment of sink to the opening.
- 8. Double check tightness of fasteners and remove excess silicone. After silicone has cured, wipe the bead with a wet cloth. This will smooth out any rough areas.

NOTE: The paper template or DXF file downloaded from www.karran.com serve as a guide. The actual sink should always be present prior to making the cutout. It is the responsibility of the installer to check all dimensions prior to cutting any countertop material.